

FirePro® Flex Seal Coated Strip



Tools required

- Sharp insulation knife or insulation saw
- Paint brush
- Sealant gun
- Tape measure /rule

Ancillary products

- FirePro® Flex Seal Linear Joint
- FirePro® HES
- FirePro® AIS

Fixing and application

1. Measure the height of the aperture to be sealed.
2. Cut the FirePro® Flex Seal Coated Strips 15% bigger than the height of the void to be filled, so when installed they are under compression.
3. Ensure substrate is clean and free of dust and debris.
4. Apply a bead of FirePro AIS around the internal edges of the aperture.
5. Install the FirePro Flex Seal Coated Strips horizontally, so that the lamellas are running horizontally.
6. Apply a bead of FirePro AIS to butt joints between different sections of Flex Seal Coated Strip and around services.
7. FirePro HES shall be used around plastic pipes in accordance with ROCKWOOL® standard details.
8. Apply FirePro Flex Seal Coating to the face of all joints between Flex Seal Coated Strip and substrate /FirePro® CB50/ FirePro® CB60.
9. Once installed, apply a second coat of FirePro Flex Seal Coating to the surfaces on both sides of the seal.

Note: Ensure adequate space above and below services to accommodate the product, for the movement levels required.

Health & safety

The mechanical effect of fibres in contact with skin may cause temporary itching.



Cover exposed skin
When working in
unventilated area wear
disposable face mask.



Clean area using vacuum
equipment.



Waste should be disposed of
according to local regulations.



Rinse in cold water before
washing.



Ventilate working area if
possible.



Wear goggles when working
overhead.

Disclaimers

ROCKWOOL Limited, its affiliates, its agents and employees and all persons acting on its or their behalf (collectively "ROCKWOOL"), disclaim any and all liability for any errors, inaccuracies or incompleteness contained in any installation guidance or in any other disclosure relating to any product.

Usage of the information remains under the sole responsibility of the purchaser and/or user.

ROCKWOOL makes no warranty, representation or guarantee regarding the information contained in the installation guidance, the suitability of the products for any particular purposes or the continuing production of any product. To the maximum extent permitted by applicable law, ROCKWOOL disclaims (i) any and all liability arising out of the application, use of any product, misuse or inability to use the product (ii) any and all liability, including without limitation special, consequential or incidental damages, and (iii) any and all implied warranties, including warranties of fitness for particular purpose, non-infringement and merchantability.

Information contained in this document is up-to-date as at the date of issue. As ROCKWOOL Limited cannot control or anticipate the conditions under which this product may be used, each user should review the information in specific context of the planned use. To the maximum extent permitted by law, ROCKWOOL Limited will not be responsible for damages of any nature resulting from the use or reliance upon the information contained in this data sheet. No express or implied warranties are given other than those implied by law.